

## ID TECH SHUTTLE COMPATIBLE DEVICES

Last Updated: September 6, 2016

DEVICE NAME	MODEL #	VERSION	CARRIER	NOTES
Acer Iconia Tab 7	A1-713	4.2.2		
Acer Iconia Tab 7 HD	A1-713HD	4.4.2		
Acer Iconia Tab A501	A501	3.2	AT&T	
Alps Tab9	TAB9	4.4.2		
Amazon Kindle Fire 5th Gen.	KFFOWI	5.1		
Amazon Kindle HD 6	KWARWI	4.4.3		
Amazon Kindle HD 7	KFASWI	4.4.3		
Asus MeMO Pad FHD 10	ME302C	4.2.2		
Asus MeMO Pad HD7	ME173X	4.2.2		
Asus Nexus 7 (2nd Gen.)	NEXUS7 (Device: FLO)	4.4.2		
Asus Nexus 7 LTE (2nd Gen.)	NEXUS7 (Device: DEB)	4.4.2		
Asus Transformer	TRANSFORMERTF101	4.0.4		
Asus Transformer Pad Infinity	ASUSTRANSFORMERPADTF70	4.0.3		
Asus Transformer Prime	TRANSFORMERPRIMETF201	4.0.3		
CasioG'zOneCommando4G	C8114G	4.1.2		Only works with longer phone plug: (ID-80110010-028)
Dell Streak 7 Tablet	DELLSTREAK7	2.2.2	T-Mobile	
HTC Aria	LIBERTY	2.2.1	AT&T	
HTC Butterfly	HTCBUTTERFLY	4.1.1		Beats audio must be turned off
HTC Desire 310	HTCDESIRE310	4.2.2		
HTC Desire 816	HTCDESIRE816	4.4.2		
HTC Desire Z	HTCVISION	2.2.1	T-Mobile	
HTC Droid DNA	HTC6435LVW	4.1.1	Verizon	Beats audio must be turned off
HTC Droid Eris	ERIS	2.1	Verizon	
HTC EVO 3D	ISW12HT	2.3.4	KDDI (Japan)	
HTC EVO 3D	PG86100	2.3.3	Sprint	
HTC EVO 4G	PC36100	2.3.3	Sprint	
HTC EVO 4G LTE	EVO	4.0.3	Sprint	
HTC EVO Shift 4G	PG06100	2.3.3	Sprint	
HTC EVO View 4G	PG41200	2.3.3	Sprint	
HTC G2	T-MOBILEG2	2.2	T-mobile	
HTC Hero	HERO200	2.1-update1	Sprint	
HTC Incredible	ADR6300	2.2	Verizon	
HTC Incredible 2	ADR6350	2.2.1	Verizon	
HTC Incredible 4G LTE	ADR6410LVW	4.0.3	Verizon	Beats audio must be turned off
HTC lele	HTCPH06130	2.3.3	AT&T	
HTC Merge	ADR6325	2.2 & 2.3.4	Verizon & US Cellular	
HTC MyTouch 3G Slide	T-MOBILEMYTOUCH3GSLIDE	2.1-update1	T-Mobile	
HTC MyTouch 4G	HTCGLACIER	2.3.4	T-mobile	
HTC MyTouch 4G Slide	MYTOUCH_4G_SLIDE	2.3.4	T-Mobile	
HTC Nexus One	NEXUSONE	2.3.6	AT&T	
HTC One	HTCONE	4.1.2	Sprint	Beats audio must be turned off
HTC One (2014)	HTC6525LVW	4.4.2	Verizon	Boom Sound must be turned off
HTC One (2014)	HTCONE_M8	4.4.2	T-Mobile	Boom Sound must be turned off
HTC One S	HTCVLE_U	4.0.3	T-Mobile	Beats audio must be turned off

HTC One V	HTCONEV	4.0.3	USCellular	Beats audio must be turned off
HTC One VX	HTCPM36100	4.0.4	AT&T	Beats audio must be turned off
HTC One X	HTCONEX	4.0.3	AT&T	Beats audio must be turned off
HTC One X+	HTCONEX+	4.1.1	AT&T	Beats audio must be turned off
HTC Rezound	ADR6425LVW	2.3.4	Verizon	
HTC Rhyme	ADR6330VW	2.3.4	Verizon	
HTC Sensation	HTCSENSATION	2.3.4		
HTC Sensation4g	HTCSENSATION4G	2.3.4	T-Mobile	
HTC Status	HTCSTATUS	2.3.3	AT&T	
HTC Thunderbolt	ADR6400L	2.2.1	Verizon	
HTC Vivid	HTCPH39100	2.3.4	AT&T	
Huawei Ascend Y330	HUAWEIY330-U05	4.2.2		
Huawei Ascend Y530	HUAWEIY530-U00	4.3		
Huawei Impulse 4G	HUAWEIU8800-51	2.2.2	AT&T	
Huawei MediaPad	HUAWEIMEDIAPAD	4.0.3		SRS option must be turned off
Huawei MyTouch Q	T-MOBILEMYTOUCHQ	2.3.6	T-Mobile	
Huawei SpringBoard	SPRINGBOARD	3.2	T-Mobile	SRS option must be turned off
Kewei	FT141B	4.4.2	NTT Docomo	
Kyocera ECHO	M9300	2.2.1	Sprint	
Kyocera Event	EVENT	4.0.4	Virgin Mobile	
Kyocera Torque	TORQUE	4.0.4	Sprint	
Lenovo ThinkPad Tablet	THINKPADTABLET	3.1		
LG Ally	ALLY	2.2.1	Verizon	
LG Enlighten	LG-VS700	2.3.4	Verizon	
LG Escape	LG-P870	4.0.4	AT&T	
LG G Flex	LG-D950	4.2.2	AT&T	
LG G Flex	LG-D959	4.2.2	T-Mobile	
LG G Flex 2	LGAS995	5.1.1		
LG G Pad 8.3	LG-V500	4.2.2		
LG G Pad 8.3	VK8104G	4.2.2	Verizon	
LG G Pad F 7.0	LGLK430	5.1.1		
LG G Pad F 8.0	LG-V496	5.0.2	Verizon	
LG G2	LG-D800	4.2.2	AT&T	
LG G2	LG-D801	4.4.2	T-Mobile	
LG G2	VS9804G	4.2.2	Verizon	
LG G2X	LG-P999	2.3.4	T-Mobile	
LG G3	LG-D850	4.4.2	AT&T	
LG G3	LG-D851	4.4.2	T-Mobile	
LG G3	VS9854G	4.4.2	Verizon	
LG G4	LG-AS991	6		
LG G4	VS986	5.1	Verizon	User has to manually increase media volume
LG Lucid 4G	VS8404G	4.0.4	Verizon	
LG MyTouch	LG-E739	2.3.4	T-Mobile	
LG Nexus 4	NEXUS4	5.0.2		
LG Nexus 5X	NEXUS5X	6.0.1		
LG Nitro HD	LG-P930	4.0.4	AT&T	
LG Optimus F3	LG-P659	4.1.2	T-Mobile	
LG Optimus F3Q	LG-D520	4.1.2	T-Mobile	
LG Optimus G	LG-E970	4.0.4	AT&T	
LG Optimus L9	LG-P769	4.0.4	T-Mobile	
LG Optimus One	LG-P500	2.3.3		
LG Optimus S	LS670	2.3.3	Sprint	
LG Optimus T	LG-P509	2.2	T-mobile	
LG Phoenix	LG-P505	2.3.4	AT&T	

LG Spectrum 2	VS9304G	4.0.4	Verizon	
LG Thrill 4G	LG-P925	2.3.5	AT&T	
LG Thrive	LG-P506	2.2.2	AT&T	
LG Vortex	VORTEX	2.2.1	Verizon	
Motorola Atrix 2	MB865	4.0.4	AT&T	Must turn off audio effect
Motorola Atrix 4G	MB860	2.3.6	AT&T	
Motorola Atrix HD	MB886	4.1.1	AT&T	
Motorola Bravo	MB520	2.2.1	AT&T	
Motorola Droid	DROID	2.2.1	Verizon	
Motorola Droid 2	DROID2	2.2	Verizon	
Motorola Droid 2 Global	DROID2GLOBAL	2.2	Verizon	
Motorola Droid 3	DROID3	2.3.4	Verizon	
Motorola Droid 4	DROID4	2.3.6	Verizon	
Motorola Droid Bionic	DROIDBIONIC	2.3.4	Verizon	For 4.1.2 OS, Audio Effect should be turned off
Motorola Droid Maxx	XT1080	4.3	Verizon	
Motorola Droid Mini	XT1030	4.3	Verizon	
Motorola Droid Pro	DROIDPRO	2.2.1	Verizon	
Motorola Droid Razr	DROIDRAZR	4.1.2	Verizon	
Motorola Droid Razr HD	DROIDRAZRHD	4.4.2	Verizon	
Motorola Droid Razr M	XT907	4.4.2	Verizon	
Motorola Droid Razr Maxx	DROIDRAZR	4.1.2	Verizon	
Motorola Droid Razr Maxx HD	DROIDRAZRHD	4.4.2	Verizon	
Motorola Droid Turbo	XT1254	5.1	Verizon	
Motorola Droid Turbo 2	XT1585	5.1.1	Verizon	
Motorola Droid Ultra	XT1080	4.3	Verizon	
Motorola Droid X	DROIDX	2.3.3	Verizon	
Motorola Droid X2	DROIDX2	2.3.4	Verizon	
Motorola Electrify M	XT901	4.1.2	US Cellular	
Motorola FlipSide	MB508	2.1-update1	AT&T	
Motorola Milestone	MILESTONE	2.1	Verizon	
Motorola Moto G	XT1028	4.3	Verizon	
Motorola Moto G	XT1032	4.3		
Motorola Moto Maxx	XT1250	4.4.4		
Motorola Moto X	XT1056	4.2.2	Sprint	
Motorola Moto X	XT1058	4.4.2	AT&T	
Motorola Moto X	XT1060	4.4.4	Verizon	
Motorola Moto X (2014)	XT1093	5.1		
Motorola Moto X (2014)	XT1097	5.0.2	AT&T	
Motorola Photon 4G	MB855	2.3.4	Sprint	
Motorola Razr i	XT890	4.0.4		
Motorola Xoom	XOOM	3.1		
Motorola XPRT	MB612	2.2.2	Sprint	
Motorola XyBoard 10.1	MZ617	3.2	Verizon	
OnePlus One	A0001	4.4.4		
OPPO R1	R829	4.2.2		
Pantech Crossover	PANTECHP8000	2.3.6	AT&T	
Quanta Ellipsis 7	QMV7A	4.2.2	Verizon	
Quanta Ellipsis 7	QMV7B	4.4.2	Verizon	
Samsung Captivate	SAMSUNG-SGH-I897	2.1-update1	AT&T	
Samsung Captivate Glide	SAMSUNG-SGH-I927	2.3.5	AT&T	
Samsung Conquer 4G	SPH-D600	2.3.6	Sprint	
Samsung Continuum	SCH-I400	2.1 -Update1	Verizon	
Samsung Droid Charge 4G	SCH-I510	2.2.1	Verizon	
Samsung Epic 4G	SPH-D700	2.2.1	Sprint	

Samsung Epic 4G Touch	SPH-D710	2.3.4	Sprint	
Samsung Exhibit 4G	SGH-T759	2.3.3	T-mobile	
Samsung Exhibit II 4G	SGH-T679	2.3.5	T-mobile	
Samsung Fascinate	SCH-I500	2.1-update 1	Verizon	
Samsung Galaxy A7	SM-A700FD	4.4.4		
Samsung Galaxy Ace	GT-S5830	2.3.3		
Samsung Galaxy Express	SAMSUNG-SGH-I437	4.0.4	AT&T	
Samsung Galaxy Gran Duos	GT-I9082L	4.2.2		
Samsung Galaxy Grand Prime	SM-G530R7	5.1.1		
Samsung Galaxy Nexus	GALAXYNEXUS	4.3	Verizon	
Samsung Galaxy Nexus	GALAXYNEXUS	4.3	GSM Ver.	
Samsung Galaxy Note	SAMSUNG-SGH-I717	4.0.4	AT&T	
Samsung Galaxy Note	SGH-I717D	4.0.4	Telus(Canada)	
Samsung Galaxy Note 10.1	GT-N8000	4.1.1		
Samsung Galaxy Note 10.1 20	SM-P600	4.3		
Samsung Galaxy Note 3	SM-N9005	4.4.2		
Samsung Galaxy Note 3	SM-N900V	4.3	Verizon	
Samsung Galaxy Note 3	SM-N900W8	4.4.2	Rogers	
Samsung Galaxy Note 4	SM-N910T	4.4.4	T-Mobile	
Samsung Galaxy Note 5	SM-N920T	5.1.1	T-Mobile	
Samsung Galaxy Note 8.0	GT-N5100	4.2.2		
Samsung Galaxy Note II	SAMSUNG-SGH-I317	4.1.2	AT&T	
Samsung Galaxy Note II	SCH-R950	4.1.2	US Cellular	
Samsung Galaxy Note II	SGH-T889	4.1.1	T-Mobile	
Samsung Galaxy Note II	SPH-L900	4.1.1	Sprint	
Samsung Galaxy Prevail	SPH-M820-BST	2.3.6	Boost Mobile	
Samsung Galaxy Prevail LTE	SM-G360P	4.4.4	Boost Mobile	
Samsung Galaxy Rugby Pro	SAMSUNG-SGH-I547	4.0.4	AT&T	
Samsung Galaxy S 4G	SGH-T959V	2.2.1	T-Mobile	
Samsung Galaxy S Blaze 4G	SGH-T769	2.3.6	T-Mobile	
Samsung Galaxy S II	SAMSUNG-SGH-I777	2.3.4	AT&T	
Samsung Galaxy S II	SGH-T989	2.3.5	T-Mobile	
Samsung Galaxy S II LTE	SGH-I727R	4.0.4	Rogers	
Samsung Galaxy S II SkyRock	SAMSUNG-SGH-I727	2.3.6	AT&T	
Samsung Galaxy S III	GT-I9300	4.0.4		
Samsung Galaxy S III	SAMSUNG-SGH-I747	4.0.4	AT&T	
Samsung Galaxy S III	SCH-I535	4.0.4	Verizon	
Samsung Galaxy S III	SCH-R530U	4.1.1	US Cellular	
Samsung Galaxy S III	SGH-T999	4.0.4	T-Mobile	
Samsung Galaxy S III	SPH-L710	4.1.1	Sprint	
Samsung Galaxy S III	SPH-L710T	4.4.2	Sprint	
Samsung Galaxy S III Mini	SM-G730V	4.2.2	Verizon	
Samsung Galaxy S4	GT-I9500	4.2.2		User must select "yes" on warning message about high volume.
Samsung Galaxy S4	SAMSUNG-SGH-I337	4.2.2	AT&T	
Samsung Galaxy S4	SCH-I545	4.3	Verizon	
Samsung Galaxy S4	SGH-M919	4.2.2	T-Mobile	
Samsung Galaxy S4	SPH-L720	4.2.2	Sprint	
Samsung Galaxy S4 Active	SAMSUNG-SGH-I537	4.2.2	AT&T	
Samsung Galaxy S5	SAMSUNG-SM-G900A	4.4.2	AT&T	
Samsung Galaxy S5	SM-G900M	4.4.2		
Samsung Galaxy S5 Active	SAMSUNG-SM-G870A	4.4.2	AT&T	
Samsung Galaxy S6	SM-G920T	5.0.2	T-Mobile	
Samsung Galaxy S6 Edge	SM-G925T	5.0.2	T-Mobile	
Samsung Galaxy S7	SM-G930T	6.0.1	T-Mobile	

Samsung Galaxy S7	SM-G930V	6.0.1	Verizon	
Samsung Galaxy S7 Edge	SM-G935V	6.0.1	Verizon	
Samsung Galaxy Tab 10.1	GT-P7500	3.2		
Samsung Galaxy Tab 10.1	GT-P7510	3.1	Verizon	
Samsung Galaxy Tab 10.1	SCH-I905	4.0.4	Verizon	
Samsung Galaxy Tab 10.1	SGH-T859	3.2	T-Mobile	
Samsung Galaxy Tab 2 10.1	GT-P5113	4.0.4		
Samsung Galaxy Tab 2 10.1	SCH-I915	4.0.4	Verizon	
Samsung Galaxy Tab 2 10.1	SPH-P500	4.1.2	Sprint	
Samsung Galaxy Tab 2 7.0	GT-P3110	4.1.1		
Samsung Galaxy Tab 2 7.0	GT-P3113	4.0.3		
Samsung Galaxy Tab 2 7.0	SCH-I705	4.0.4	Verizon	
Samsung Galaxy Tab 3 7.0	SAMSUNG-SM-T217A	4.2.2	AT&T	
Samsung Galaxy Tab 3 7.0	SM-T210R	4.1.2		
Samsung Galaxy Tab 3 7.0	SM-T217S	4.2.2	Sprint	
Samsung Galaxy Tab 3 7.0	SM-T217T	4.2.2	T-Mobile	
Samsung Galaxy Tab 4 10.1	GT-P5200	4.2.2		
Samsung Galaxy Tab 4 10.1	SAMSUNG-SM-T537A	4.4.2	AT&T	
Samsung Galaxy Tab 4 10.1	SM-T530NU	5.0.2		
Samsung Galaxy Tab 4 10.1	SM-T537V	4.4.2	Verizon	
Samsung Galaxy Tab 4 7.0	SM-T230NU	4.4.2		
Samsung Galaxy Tab 4 7.0	SM-T231	4.2.2		
Samsung Galaxy Tab 4 7.0	SM-T237P	4.4.2	Sprint	
Samsung Galaxy Tab 4 8.0	SM-T337V	4.4.2		
Samsung Galaxy Tab 7.0	SCH-I800	2.3.5	Verizon	
Samsung Galaxy Tab 7.0	SPH-P100	2.3.4	Sprint	
Samsung Galaxy Tab 7.0 Plus	SGH-T869	3.2	T-Mobile	
Samsung Galaxy Tab 7.7	SCH-I815	3.2	Verizon	
Samsung Galaxy Tab 8.9	GT-P7310	3.1		
Samsung Galaxy Tab 8.9	SAMSUNG-SGH-I957	3.2	AT&T	
Samsung Galaxy Tab E 8.0	SM-T337P	5.1.1	Sprint	
Samsung Galaxy Tab E 9.6	SM-T567V	5.1.1	Verizon	
Samsung Galaxy Tab Pro 12.2	SM-T900	4.4.4		
Samsung Galaxy Tab S 10.1	SM-T800	4.4.2		
Samsung Galaxy Tab S 8.4	SAMSUNG-SM-T707A	4.4.2	AT&T	
Samsung Galaxy Tab S 8.4	SM-T700	4.4.2		
Samsung Galaxy Tab S2	SM-T710	5.1.1		
Samsung Galaxy Y	GT-S5360B	2.3.6		
Samsung Illusion	SCH-I110	2.3.5	Verizon	
Samsung Infuse 4G	SAMSUNG-SGH-I997	2.3.6	AT&T	
Samsung Intercept	SPH-M910	2.2.1	Sprint	
Samsung Nexus 10	NEXUS10	4.2		
Samsung Nexus S	NEXUSS	2.3.3	T-mobile	
Samsung Nexus S 4G	NEXUSS4G	2.3.7	Sprint	
Samsung Replenish	SPH-M580	2.2.2	Sprint	
Samsung Rugby	SAMSUNG-SGH-I847	2.3.6	AT&T	
Samsung Sidekick 4G	SGH-T839	2.2.1	T-mobile	
Samsung Stratosphere	SCH-I405	2.3.5	Verizon	
Samsung Transform	SPH-M920	2.2.2	Sprint	
Samsung Vibrant	SGH-T959	2.1-update1	T-Mobile	
SamsungGalaxyTab310.1	GT-P5210	4.2.2		
Sony Xperia TL	LT30AT	4.0.4	AT&T	
Sony Xperia Z	C6603	4.4.4		User has to manually increase volume
Sony Xperia Z	C6606	4.1.2	T-Mobile	

Sony Xperia Z Ultra	C6802	4.4.4		
Sony Xperia Z Ultra	C6833	4.4.4		
Toshiba Excite	AT300	4.0.3		
Unitech Tablet	ETBW11AA	3.2		
ZTE Fury	N850	2.3.6	Sprint	